

Detection of Food Adulteration using Sensors and Microcontrollers

Harsh Hegde 16ECE1007

Rahul Rajesh 16ECE1019

Under the guidance of Dr. Lalat Indu Giri

Department Of
Electronics And Communication Engineering
National Institute of Technology Goa

June 12, 2020



- ➊ Problem Statement and Importance
- ➋ Motivation
- ➌ Methods and Alternatives
- ➍ Design and Components
- ➎ Results
- ➏ Conclusion

- ❶ Food Adulteration is widespread in India
- ❷ Formaldehyde, a carcinogen - used to preserve fish in Asia
- ❸ Generally used to preserve dead bodies.
- ❹ Widely used to improve shelf life
- ❺ Has been a hot topic in Goa over the years.
- ❻ No concrete solution



Figure: The Hindu, 17 October 2018

Harsh Hegde 16ECE1007Rahul Rajesh 16ECE1019 Detection of Food Adulteration using Sensors

- ➊ To design a reliable food adulteration detection device to detect presence of Formaldehyde, Benzene, Toluene adulteration.
- ➋ To have both quantitative and qualitative analysis of the adulterant
- ➌ To have fast response time and accuracy during detection

- ④ Analytical Methods
 - Gas Chromatography-Mass Spectrometry [1]
 - High Performance Liquid Chromatography [2]
- ② Electrochemistry and Fluorometric Methods
- ③ Colorimetric and Spectrophotometric Methods [3]



Figure: Formaldehyde Meter Z-300

Source: BC Group International, Inc.



Figure: FoodSniffer

Source: ARS Lab US, Inc.

- 1 Formaldehyde, a volatile organic compound
- 2 Conductivity increases with formaldehyde content in surroundings.
- 3 Conductivity increase is gauged by a MOS sensor
- 4 Conductivity is mapped to concentration levels.

[4]

- Food sniffed using VOC Gas Sensor(E-Nose)
- Values fed and decoded via microcontroller
- Detection output is displayed onto an LCD screen

[4]

Block Diagram




Figure: Block Diagram

- Our sensor checks the increase in conductivity and thereby predicts the concentration. The output is generally from 0.1V to 0.2 V
- We calibrate this value to the normal room temperature level for near perfect readings.
- The microcontroller receives this data and checks it for 2 thresholds of 150ppm and 300ppm
- If less than 150ppm-classified into safe
- If less than 300ppm-classified into unsafe
- If more than 300ppm-classified into Danger

Sensor Specification

- Grove - HCHO Sensor
- Very high sensitivity and stability, concentration till 1ppm.
- Operating Voltage: $5.0V \pm 0.3V$
- Sensor Resistance Value(R_s): 10K-100K(in 10ppm HCHO)
- Sensitivity: $R_s(\text{in air})/R_s(10\text{ppm HCHO}) > 5$



Figure: Grove HCHO Sensor

Zhengzhou Winsen Electronics
Technology Co., Ltd.

Sensor Specification

- DHT11 Temperature Humidity Sensor
- Humidity sensing component, a NTC temperature sensor (or thermistor) and an IC on the back side of the sensor.
- Linear relationship between resistance and temperature as given by- $R=kT$.




Figure: Circuit Diagram

Aosong Electronics Co., Ltd




Figure: DHT11 Sensor

Aosong Electronics Co., Ltd

We took readings at room temperature of the surrounding air and a bottle of water to check if the device is working.

Sub	Time	Sensor Value	Concentration	Temp	Humidity
Air	14:12:33	7	1.00	30	60
Air	14:12:50	6	1.00	30	60
Water	14:13:02	6	3.00	30	60
Water	14:15:08	7	4.00	30	60

- 1 We tested the device on Ethanol Solutions of different concentration.
- 2 Formaldehyde was not easily available but ethanol was used instead as it is a suitable replacement.
- 3 Ethanol is considered a volatile organic compound by the National Pollutant Inventory.
- 4 We began with a 40% solution of ethanol and kept diluting it.

Table: Ethanol Concentration and Sensor Value (Experiment-1)

Serial No.	Concentration	Sensor Value
1	1 ml 40% C ₂ H ₅ OH	651
2	1 ml 40% C ₂ H ₅ OH + 1ml H ₂ O	563
3	1 ml 20% C ₂ H ₅ OH + 1ml H ₂ O	554
4	1 ml 10% C ₂ H ₅ OH + 1ml H ₂ O	476
5	1 ml 5% C ₂ H ₅ OH + 1ml H ₂ O	398
6	1 ml 2.5% C ₂ H ₅ OH + 1ml H ₂ O	301
7	1 ml 1.25% C ₂ H ₅ OH + 1ml H ₂ O	255
8	1 ml 0.625% C ₂ H ₅ OH + 1ml H ₂ O	203
9	1 ml 0.3125% C ₂ H ₅ OH + 1ml H ₂ O	130
10	1 ml 0.15625% C ₂ H ₅ OH + 1ml H ₂ O	93
11	1 ml 0.078125% C ₂ H ₅ OH + 1ml H ₂ O	86
12	1 ml 0.0390625% C ₂ H ₅ OH + 1ml H ₂ O	74
13	1 ml 0.01953125% C ₂ H ₅ OH + 1ml H ₂ O	63
14	1 ml 0.009765625% C ₂ H ₅ OH + 1ml H ₂ O	63

Table: Ethanol Concentration and Sensor Value (Experiment-4)


Serial No.	Concentration	Sensor Value
1	37% C ₂ H ₅ OH	706
2	37% C ₂ H ₅ OH + 1ml H ₂ O	705
3	18.5% C ₂ H ₅ OH + 1ml H ₂ O	705
4	9.25% C ₂ H ₅ OH + 1ml H ₂ O	658
5	4.625% C ₂ H ₅ OH + 1ml H ₂ O	593
6	2.3125% C ₂ H ₅ OH + 1ml H ₂ O	535
7	1.15625% C ₂ H ₅ OH + 1ml H ₂ O	408
8	0.578125% C ₂ H ₅ OH + 1ml H ₂ O	244
9	0.2890625% C ₂ H ₅ OH + 1ml H ₂ O	203
10	0.14453125% C ₂ H ₅ OH + 1ml H ₂ O	140
11	0.072265625% C ₂ H ₅ OH + 1ml H ₂ O	115
12	0.0361328125% C ₂ H ₅ OH + 1ml H ₂ O	83
13	0.01806640625% C ₂ H ₅ OH + 1ml H ₂ O	68
14	0.009033203125% C ₂ H ₅ OH + 1ml H ₂ O	68

- ➊ Sensor value is found maximum for 40% ethanol which is termed as pure ethanol solution.
- ➋ As the ethanol concentration in the solutions is decreased, the sensor value is also decreased.
- ➌ Sensor values do not start from zero rather they start from 50 to 80ppm which indicates the lowest concentration of ethanol.
- ➍ When the concentration of ethanol is very large, the sensor value goes into saturation and hold a constant value.

Results

Data from all experiments are plotted on a single two dimensional graph.

Figure: Plot



(6).jpg

- ➊ The graph is almost linear when the concentration of ethanol is about 5 to 10%
- ➋ When the concentration of ethanol is above 10%, the concentration of Ethanol vs. Sensor Value graph is a nonlinear one.
- ➌ Here, we defined two different threshold values of the sensor at 150 and 300 ppm.
- ➍ The threshold values can be easily changed in the program to match the national and international safety limits.

- ➊ When the concentration of adulterant is too high, the volatile organic compound (VOC) gas sensor cannot show accurate value.
- ➋ The highest saturated value of volatile organic compound (VOC) gas sensor is recorded as 706 units.
- ➌ But as we are concerned with the safety of edible products, this limitation does not cause any problem.
- ➍ Because for much lower concentration of adulterant, the safety limits of foods will be exceeded which can be measured accurately by our kit.

Advantages

- ① Low cost due to cheap materials
- ② Efficient and accurate Readings
- ③ Qualitative and quantitative Analysis
- ④ Easy to use and commercially Viable

- 1 Our microcontroller-based food adulterant detector kit can detect the concentration level of adulterant present in solid as well as liquid edible samples.
- 2 It can also determine and display both the humidity and temperature of that sample.
- 3 This device can help people to be well aware of the safety and the purity of the foods before consumption.

- 1 Bianchi, F., M. Careri, M. Musci, and A. Mangia. "Fish and food safety: Determination of formaldehyde in 12 fish species by SPME extraction and GC-MS analysis." *Food Chemistry* 100, no. 3 (2007): 1049-1053.
- 2 Wahed, P., Md A. Razzaq, S. Dharmapuri, and M. Corrales. "Determination of formaldehyde in food and feed by an in-house validated HPLC method." *Food chemistry* 202 (2016): 476-483. Uddin, Riaz, Moin Ibna Wahid,
- 3 Wongniramaikul, Worawit, Wadcharawadee Limsakul, and Aree Choodum. "A biodegradable colorimetric film for rapid low-cost field determination of formaldehyde contamination by digital image colorimetry." *Food chemistry* 249 (2018): 154-161.
- 4 Uddin, Riaz, Moin Ibna Wahid, Tasbira Jasmeen, Naz Hasan Huda, and Kumar Bishwajit Sutradhar. "Detection of formalin in fish samples collected from Dhaka City, Bangladesh." *Stamford Journal of Pharmaceutical Sciences* 4, no. 1 (2011): 49-52.
- 5 Kesselmeier, John, and Michael Staudt. "Biogenic volatile organic compounds (VOC): an overview on emission, physiology and ecology." *Journal of atmospheric chemistry* 33, no. 1 (1999): 23-88.

Thank You